


MG-220 MEGAPHONE

WARNING: THIS PRODUCT REQUIRES 8 "D" CELL BATTERIES, WHICH MUST BE LOADED CORRECTLY

PLEASE READ THE FOLLOWING BEFORE USING THIS PRODUCT

The MG-220 requires 8 x "D" cells, which must be loaded into the compartment the correct way round. If they are loaded incorrectly, the megaphone will not work and this may also cause damage to the unit.

Note: The 12V connector on the underside is **NOT** for re-charging.



Plastic sleeves are provided for loading the D cells into the compartment in pairs. When loaded correctly, the compartment should appear as shown below.

