


INSTRUCTIONS FOR SCART/VIDEO UNIT

108.123.

This unit has been designed to allow for the connection of up to 3 pieces of equipment to a Television, which has a Scart facility.

The unit also allows you to record from one piece of equipment whilst watching the television. For example you can record from a DVD, VCR or a Games Console on to your main VCR.

Installation



NOTE:

Some devices may support the higher quality 'RGB' mode, for example DVD players.

If you have a fully implemented scart cable connected to parts A, B or C, of the switch box, and from the switch box to the TV you must press the 'RGB' button to the 'On' position. This will ensure that the higher quality signal is used.

IMPORTANT

Not all DVD players or televisions support this mode. Consult your dealer or manufacturers instructions. Recording from DVD is dependant on your VCR and DVD software being used

RECORDING

Please note that recording from DVD/VCR may result in loss of sound and/or picture quality due to the built-in copyright protection of DVD/VHS pre-recordings.

VIEWING

When viewing from a DVD/VCR player connected to Input B or C ALWAYS ensure that the recording switch (C-A or B-A) opposite the scart input socket your device is connected to is in

E.g.

DVD/VCR in Input C Switch C-A OFF

DVD/VCR in Input B Switch B-A OFF