

Pocket Scale

For the purpose of using and maintaining the pocket scale, please read this instruction completely before operating.

SPECIFICATIONS

- Equipped with a high precision “strain-gauge” sensor and high capability CPU to ensure the weighing accuracy.
- Capacity:0.3g-500g
- Tare function.
- Auto power off.
- Show low voltage

TECHNIC PARAMETER

1. Capacity: 0.3g-500g
2. Show numerical value: 0.1g
3. Battery: 2pcs AAA Battery (3V)
4. work temperature: 5°C- 60°C
5. display usage: LCD Show, 4 units,

KEY FUNCTION

- ON/OFF key: Power on, Power off,
- TARE key: Tare function
- UNIT key: Unit exchange (g/gn/oz/ct)
- LIGHT key: Background lamp


OPERATION

- Take out the scale, and open up the battery cover, install the batteries to the battery case.
- Put the scale on a flat table, and ensure it steady.

WEIGHTING STEP

- ① Under the state press the key of “ON/OFF” to power on, the scale will be zero “0.00” appear on the display after 2 seconds.
- ② Press the key of “UNIT”, you can change “g”, “gn”, “oz”, “ct” .
- ③ Under the weight state, put the container on the flat, LCD will show the weight of container.
- ④ Press the key of “TARE”, LCD shows zero. Clear the weight of the container, then put the goods into container, the weight will appear on the display.
- ⑤ Press the key of “ON/OFF” again , power off.
- ⑥ When the ambience is very dark, you can press the key of “LIGHT”, it will be shine ,press it again, the light is off.

ERROR DISPLAY INTRODUCTION

- When the scale is over loaded, the “EEEE” will appear on the display.
- When the screen shows “ ”, it means that the power isn’t enough, please change the batteries as soon as possible.
- When the screen shows “OUTZ” or “UNST”, and power off. It means the object over loaded or unsteady.

INTRODUCTION OF USING AND INSTALLING THE BATTERIES

- Use 2PCS AAA batteries.
- When change the batteries, please open the battery cover on the back, put 2PCS AAA batteries in the battery case (make the positive poles towards), then close the battery cover tight.
- The product use 2PCS AAA batteries, please install it before using.

ADVICE FOR USE AND CARE

●Put the scale on a clean and flat table.
●The max. weight of the scale is 500g, which included the weight before tare.
●To ensure the life of the scale, do not put the scale under wet, hot & cold condition.
●The product belongs to high precision electronic weighing apparatus, please do not press or drop the scale otherwise the scale is easy to damage.
●If the scale surface is dirty, please clean the scale with soft cloth, do not use any chemical detergent and allow water to get inside the scale.
●The product is for small goods weighing only, do not use for legal trade.
●If the result appears improperly, please check about whether the batteries and the touching point contact well. Replace for new batteries if used for a long time already, then try again. If necessary, contact the local franchisers or telephone company.